

User Guide for sendQuick SMS Gateway

FTP to send SMS

1. To activate the FTP Service

To activate the FTP service, login as Server Administrator > SMS System Setup > Enable FTP to SMS Service.

Then, Save Setting > Activate Setting.

2. To configure the FTP account and Password

- http://sendQuick_server_IP/appliance/ URL:
- username and password Enter admin
- 'Change Password' from Menu Then click
- new password at 'change smsapp password' Enter your

FTP Folder Name on the server: /smsftp/

This is the directory that you will be placing the file, once you login as 'smsapp' username

3. FTP File Structure & Format

(a) File Structure

Field	Size	Remarks
Hand Phone	x(15)	Keep to numeric
Message	x(160)	

(b) File Format

The data in the file must be according to the following sequence and using comma delimiter (comma separated value). There need to be a double-quote for the data (as below). When the data file is created by Excel spreadsheet, the double-quote is being automatically created. You can check the formatting by opening the file in a text editor, like Notepad.

handphone,message
handphone1,message1

Eg:

"96367680","how are you?"
"96180556","I am doing fine"

(c) File Type

File type allowed: *text file with extension .msg*. There are 2 text files to upload by FTP (*.msg and *.end). The data must be saved in the .csv and .end is just a blank file. At first, you have to put .msg file in the folder (/home/smsapp/smsftp) and after successfully uploaded the .msg file, you have to put the .end file in that folder to inform the system that file uploading is completed.